

Powertube recommended selection and release adjustment:

WARNING: The NTN binding is not certified according to the ISO standard.

1. Find skier weight and boot size/length

2. Power Tubes

Rottefella offers four different Power Tubes, which are selected based on a color code:

White: extra soft

Green: soft

Blue: medium

Red: hard

Rottefella recommends white or green for small boots (<26.5 mondo), and green or blue for large boots (>26.5 mondo). The bindings (small and large size) are sold with these Power Tube options as standard. The red Power Tube is for skiers who prefer hard springs.

3. Release Settings

Rottefella recommends dividing skiers into three groups:

Beginner: Skies conservatively/low speed. Set value one below scale.

Average: Skies moderately/variety of speed. Set value according to scale.

Expert: Skies aggressively/high speed. Set value one above scale.

Note: If skiers age is above 50 years, set value one below scale.

4. Adjustment of Power Tubes

Adjust Power Tubes by turning them to the correct setting, using the printed scale from 1-5 on the Power Tubes as reference. See NTN technical manual for details regarding correct adjustment.

Warning!: Power Tubes should never be set above recommended

Recommended maximum release settings: **warning: setting should never be above recommended setting.**

Kg/lbs	Boot size/length.															
	271-290 mm 24,0-26,0 mondo 38-40,5 europe				291-310 mm 26,5-28,0 mondo 41-43 europe				311-330 mm 28,5-30,0 mondo 44-45,5 europe				331 mm - 32,0 mondo - 46 europe -			
36-41kg 79-91lbs	1				2	1			2	1			3	1		
42-48kg 92-107lbs	2	1			3	1			3	1			3	2	1	
49-57kg 108-125lbs	3	2	1		4	2	1		4	2	1		5	3	1	
58-66kg 126-147lbs	4	2	1		5	3	1		5	3	2	1	5	4	2	1
67-78kg 148-174lbs	5	3	2	1		4	2	1		4	3	1		5	3	1
79-94kg 175-209lbs		4	3	2		5	3	2		5	3	2		5	4	2
95+ kg 210+ lbs		5	3	2		5	4	2			4	2			4	3